

Cheap PowerBook G3 Feet — Lombard & Pismo Models

The enclosed 5/16" feet are **MintCraft Clear Bumpers** P/N 653-5869 made for Orgil, Inc. of Memphis, TN.

Installation:

- 1) Clean any residual adhesive from the foot wells on the bottom of the PowerBook case.
- 2) Wipe the wells with alcohol if possible, to make sure that there is no grease or other film that could affect the bonding of the self adhesive on the new feet. Make sure that the foot wells are dry and clean!
- 3) When applying the feet to the wells, do not touch the adhesive as grease from your fingertips will contaminate the bond.
- 4) Press the feet firmly and hold for a minute or two. Set the Powerbook on a hard, flat surface for a while so the adhesive gets a chance to make good contact with the wells.

Thank you,

Marc W. Wolfgram

MacCetera LLC

735 River Reserve Drive

Hartland, WI 53029

262-367-8800 office

262-370-1768 mobile

<http://www.MacCetera.com>

marc@maccetera.com

powerbookfeet.pdf – Rev A

Copyright © 2005 by MacCetera LLC and Marc W. Wolfgram — All rights reserved